



I. Driver Features

1. Command Format

This device is controlled through a combination of RS-232 and IR commands; both are necessary for full control of the device.

2. RS-232 Commands

IR Commands

| | | | | |
|---------------|--------------------|-------------|------------|-----------------|
| Power On | Source: Video | Menu | Blank | Zoom Up |
| Power Off | Source: S-Video | Adj Up | Auto Image | Zoom Down |
| Volume Up | Source: Computer 1 | Adj Down | Focus Up | Lens Shift Up |
| Volume Down | Source: Computer 2 | Adj Left | Focus Down | Lens Shift Down |
| Keystone Up | Freeze | Adj Right | Mute | |
| Keystone Down | | Left Click | P in P | |
| | | Right Click | | |

3. Other Driver Features

Default Power Status Feedback: RS-232 Polling
Projector Restart Lockout Timer (Default): 72 Seconds